



These take power from Fuse 5 (15 amp) and switch off when the load shed relay pulls in. There are usually two spare mounting points in the relay box where you can screw new relay sockets to. They are minimal invasion into the existing wiring loom i.e. none for the heated grips and just one wire (hi-beam feed) for the fog / driving lights.